INSTRUKCJA UŻYTKOWANIA – PUDEŁKO NA ZABAWKI LEGOS

Przed rozpoczęciem montażu i użytkowania, należy dokładnie zapoznać się z niniejszą instrukcją.

Pudełko na zabawki należy użytkować, konserwować, czyścić oraz przechowywać zgodnie z poniższą instrukcją. Jeżeli pudełko zostało uszkodzone lub jakiś z elementów nie działa poprawnie należy niezwłocznie zaprzestać z korzystania z produktu. Producent nie ponosi odpowiedzialności za korzystanie z pudełka na zabawki niezgodnie z przeznaczeniem oraz poniższą instrukcją.

Ważne! Instrukcję należy zachować na przyszłość, by w razie potrzeby do niej wrócić.

UŻYTKOWANIE, CZYSZCZENIE I KONSERWACJA

1. Przed rozpoczęciem użytkowania upewnij się, że pojemnik nie jest uszkodzony (np. nie jest pęknięty, nie ma wystających ostrych krawędzi, nie przewraca się).
2. Upewnij się, że pojemnik na zabawki jest prawidłowo zmontowany.
3. Umieść pojemnik na zabawki w bezpiecznym miejscu, z dala od źródeł ciepła i wilgoci.
4. Nie przeciążaj pojemnika na zabawki.
5. Regularnie czyść produkt (w przypadku zabrudzeń najlepiej przecierać lekko wilgotną szmatką lub zastosować rozcieńczony w ciepłej wodzie łagodny środek myjący, a następnie wytrzeć do sucha; nie należy używać twardych środków: gąbek, szczotek i innych produktów do czyszczenia mających ścierną powierzchnię, która może uszkodzić elementy pudełka).

OSTRZEŻENIE! Elementy opakowania (w tym karton, torby foliowe itd.) nie są zabawkami. Należy trzymać poza zasięgiem dzieci, istnieje ryzyko uduszenia, bądź uszczerbku na zdrowiu. Produkt zawiera małe elementy, które mogą zostać połknięte przez dzieci. Produkt powinien być używany pod nadzorem osoby dorosłej.

Producent:
Mirosław Gockowiak
Ciele, ul. Przylesie 3
86-005 Białe Błota, Polska
Wyprodukowano w ChRL

INSTRUCTIONS FOR USE - TOY BOX

Before starting installation and use, please read this manual carefully.

Toy box should be used, maintained, cleaned, and stored in accordance with the instructions below. If the box has been damaged or any of its components are not functioning properly, discontinue use of the product immediately. The manufacturer is not responsible for the use of the toy box contrary to its intended purpose and the instructions below.

Important! Keep these instructions for future reference.

USE, CLEANING AND MAINTENANCE

1. Before use, ensure that the container is not damaged (e.g. no cracks, no sharp edges, does not tip over).
2. Ensure that the toy container is correctly assembled.
3. Place the toy box in a safe place, away from sources of heat and moisture.
4. Do not overload the toy box.
5. Clean the product regularly (if dirty, it is best to wipe it with a slightly damp cloth or use a mild detergent diluted in warm water, then wipe dry; do not use hard cleaning agents such as sponges, brushes or other cleaning products with an abrasive surface that could damage the box components).

WARNING! Packaging components (including cardboard boxes, plastic bags, etc.) are not toys. Keep out of reach of children, as there is a risk of suffocation or injury. The product contains small parts that may be swallowed by children. The product should be used under adult supervision.

Producer:
Mirosław Gockowiak
Ciele, ul. Przylesie 3
86-005 Białe Błota, Poland
Made in China